



# The ASHRAE Guide for Buildings in Hot & Humid Climates

Second Edition

Expanded with  
New Content

Lewis G. Harriman III  
Joseph W. Lstiburek



American Society of Heating, Refrigerating and Air-Conditioning Engineers, Inc.

|  |           |   |            |
|--|-----------|---|------------|
| <b>1. Introduction.....</b>                                    | <b>8</b>  | 9. First lower the dew point... then raise the thermostat.....    | <b>59</b>  |
| <b>2. Improving Thermal Comfort .....</b>                      | <b>12</b> | 10. Invest in regular tune-ups (Constant commissioning).....      | <b>61</b>  |
| Key Points .....   | 13        | <b>5. Avoiding Bugs, Mold &amp; Rot .....</b>                     | <b>68</b>  |
| Thermal Comfort - A Moving Target .....                        | 13        | Key Points .....  | 69         |
| Thermal comfort is governed by expectations .....              | 14        | Excess Moisture Leads to Bugs, Mold & Rot.....                    | 69         |
| Improving the percentage of comfortable people .....           | 14        | Human Health Effects of Bugs, Mold & Rot .....                    | 70         |
| Dynamic & social nature of comfort perception .....            | 15        | Lessons Learned and Forgotten.....                                | 70         |
| Avoiding cold buildings in hot climates .....                  | 16        | Mold growth - water activity vs. rh.....                          | 71         |
| Architecture - The Foundation of Comfort.....                  | 17        | The owner—not the law—makes the key decisions ....                | 74         |
| HVAC Suggestions for Better Comfort .....                      | 21        | Suggestions for owners and Architects .....                       | 74         |
| 1. Design HVAC systems for real clothing preferences .....     | 21        | Suggestions for the HVAC designer .....                           | 81         |
| 2. Dry ventilation air helps avoid temperature swings .....    | 22        | Suggestions for contractors .....                                 | 84         |
| 3. Constantly-cold coils can also dry air effectively.....     | 22        | Suggestions for building operators .....                          | 87         |
| 4. Drier air expands the comfort range in mixed uses.....      | 23        | Assessing Mold Risk in Existing Buildings .....                   | 89         |
| 5. Capacity modulation avoids sharp changes.....               | 24        | Bacteria: locate any standing water, then drain it or dry it..... | 89         |
| 6. Higher velocity diffusers avoid “cold air dumping” .....    | 25        | Mold - keep moisture content below 14% WME.....                   | 90         |
| <b>3. Managing Ventilation Air .....</b>                       | <b>28</b> | Measuring moisture .....  | 91         |
| Key Points .....   | 29        | Locating excess moisture in buildings.....                        | 92         |
| Measuring and conserving ventilation air.....                  | 29        | Risky Misconceptions and Half-truths.....                         | 97         |
| Drying ventilation air—all the time.....                       | 32        | <b>6. Improving Sustainability .....</b>                          | <b>106</b> |
| Avoiding building suction and infiltration .....               | 34        | Key Points .....  | 107        |
| Greater O & M attention for ventilation components ....        | 35        | Advancing Beyond Theory To Practice.....                          | 107        |
| <b>4. Reducing Energy Consumption ..</b>                       | <b>38</b> | Chapter 6 is an index to sustainability decisions .....           | 108        |
| Key Points .....   | 39        | More Durable = More Sustainable .....                             | 108        |
| Suggestions For Reducing Energy Use.....                       | 42        | Don’t build in flood zones and swamps.....                        | 108        |
| 1. Reduce the cooling load from windows .....                  | 43        | Enclosure design which keeps out water .....                      | 109        |
| 2. Avoid west-facing glass .....                               | 45        | Materials which tolerate frequent wetting .....                   | 109        |
| 3. Reduce the heat from lights, using daylighting .....        | 46        | Less Energy = More Sustainable .....                              | 110        |
| 4. Build an air tight exterior enclosure.....                  | 49        | Enclosure design which keeps out heat and humidity.....           | 110        |
| 5. Commission new buildings and mechanical systems.....        | 51        | HVAC design which keeps out heat and humidity .....               | 111        |
| 6. Seal up all duct connections, air handlers and plenums..... | 54        | HVAC design which matches energy to occupancy .....               | 111        |
| 7. Reduce ventilation air when occupants leave .....           | 55        | More Maintainable = More Sustainable.....                         | 111        |
| 8. Recover waste energy from exhaust air and condensers.....   | 56        | Accounting allows—or prevents—sustainability.....                 | 111        |
|  |           | Budget for constant commissioning—then do it.....                 | 112        |
|  |           | Access, access, access.....                                       | 113        |

## The Building Enclosure

|   |            |
|---|------------|
| <b>7. Elements of a Perfect Wall .....</b>                      | <b>116</b> |
| Towards a Perfect Wall .....                                    | 117        |
| The layers are the same for roofs and foundations.....          | 118        |
| Wall and roof layers must connect.....                          | 119        |
| Translating basic principles into real walls .....              | 119        |
| <br>  |            |
| <b>8. Keeping Water Out .....</b>                               | <b>122</b> |
| Key Points .....  | 123        |
| Roof Overhangs Come First.....                                  | 124        |
| Sill Pans .....   | 126        |
| Flashing .....  | 126        |
| Drainage Planes In Walls.....                                   | 128        |
| Crawl Spaces .....  | 133        |
| Site and Foundation Drainage .....                              | 135        |
| <br>  |            |
| <b>9. Keeping Heat Out.....</b>                                 | <b>140</b> |
| Key Points .....  | 141        |
| Owner & Architectural Designer Decisions.....                   | 141        |
| Reduce the glazing and shade the remainder .....                | 141        |
| Design high, horizontal glazing for daylighting.....            | 143        |
| Control lighting power according to daylight.....               | 145        |
| Install continuous insulation, outboard.....                    | 146        |
| Allow money for demand-controlled ventilation .....             | 147        |
| Allow ceiling height for ducted supply and return.....          | 148        |
| HVAC Designer Decisions .....                                   | 149        |
| Seal up all air-side joints and connections .....               | 149        |
| Don't use building cavities to carry supply or return air.....  | 150        |
| Install demand-controlled ventilation .....                     | 151        |
| Don't let air economizers fill the building with humid air..... | 151        |
| Use exhaust air to precool and predry ventilation air .....     | 152        |
| Keep the indoor dew point low.....                              | 153        |
| <br>  |            |
| <b>10. Lessons From Storms .....</b>                            | <b>156</b> |
| Resisting wind and rain .....                                   | 157        |
| Resisting storm surges and floods.....                          | 157        |
| Materials and assemblies which tolerate water.....              | 158        |
| Assemblies which dry easily .....                               | 162        |

## HVAC Design

|  |            |
|--|------------|
| <b>11. Dehumidification Loads .....</b>                          | <b>166</b> |
| Dehumidification (DH) Loads .....                                | 167        |
| The Estimate Begins With Owner's Decisions.....                  | 167        |
| Step 1 - Selecting the outdoor design condition .....            | 167        |
| Step 2 - Selecting the target maximum indoor dew point.....      | 168        |
| Step 3 - Quantifying & locating the people in the building ..... | 169        |
| After Owner's Decisions, Engineering Begins .....                | 171        |
| Step 4 - Estimating the ventilation & makeup air load.....       | 171        |
| Step 5 - Estimating the infiltration load .....                  | 172        |
| Step 6 - Estimating the load from people .....                   | 174        |
| Step 7 - Estimating the load from door openings .....            | 175        |
| Step 8 - Estimating the minor loads .....                        | 177        |
| <br>   |            |
| <b>12. Cooling Loads .....</b>                                   | <b>190</b> |
| Key Points .....   | 191        |
| Quantify glass-related loads to improve design.....              | 191        |
| Separate and calculate the dehumidification loads....            | 195        |
| Calculate ventilation loads at peak dew point.....               | 197        |
| Enthalpy heat recovery reduces peak cooling loads ..             | 198        |
| Don't overestimate office plug loads.....                        | 199        |
| <br>   |            |
| <b>13. Dehumidification Systems.....</b>                         | <b>202</b> |
| Key Points .....   | 203        |
| Deliver air drier than the control condition .....               | 204        |
| Control requires dedicated DH components.....                    | 204        |
| Size DH equipment based on the peak dew point.....               | 205        |
| DH performance based on weight of water removed ..               | 207        |
| Design for dew point control instead of rh control .....         | 211        |
| Avoiding common problems in DH design.....                       | 212        |
| Ways to reduce DH-related energy.....                            | 217        |
| <br>   |            |
| <b>14. Cooling Systems.....</b>                                  | <b>224</b> |
| Key Points .....   | 225        |
| Independent dehumidification and ventilation .....               | 225        |
| Extra cooling capacity does not dehumidify .....                 | 227        |
| Don't double-up the safety factors .....                         | 229        |
| Measure, control and dry the ventilation air.....                | 231        |

## HVAC Design

|   |     |
|---|-----|
| Focus carefully on the exterior glass .....         | 232 |
| Design air systems which are really air-tight ..... | 233 |
| Cautions for buildings with operable windows .....  | 234 |
| Cautions for comfort in hot and humid climates..... | 235 |

## 15. Ventilation Air Systems ..... 238

|  |     |
|--|-----|
| Key Points .....   | 239 |
| Ventilation Dehumidification and Air Cleaning .....        | 240 |
| Drying ventilation air .....                               | 240 |
| Filtering particles .....                                  | 242 |
| Filtering gaseous pollutants - emphasizing ozone .....     | 245 |
| Effective Ventilation Air Distribution.....                | 246 |
| Reducing The Cost Of Ventilation.....                      | 248 |
| How Much Air & Where - ASHRAE Std 62.1 .....               | 254 |
| Access for maintenance is now a requirement .....          | 259 |
| Use the peak dew point for DH calculations.....            | 259 |
| 65% rh upper limit - a 55°F dew point is a better one..... | 260 |
| Key Maintenance Aspects Of Ventilation.....                | 263 |

## 16. Airtight HVAC Systems ..... 270

|  |     |
|--|-----|
| Key Points .....   | 271 |
| Airtight Systems... Are They Necessary? .....                        | 271 |
| Energy consumption and leaky air systems .....                       | 271 |
| Mold and leaky air systems .....                                     | 272 |
| How Much Building Leakage Is HVAC-Driven?.....                       | 272 |
| Designers' Guide To Limiting Air Leakage .....                       | 277 |
| Avoid return and supply air plenums.....                             | 277 |
| Roof curbs.....  | 278 |
| Connections to and from air handlers.....                            | 279 |
| Seal <i>all</i> supply, return and exhaust air duct connections..... | 279 |
| In-wall packaged AC units and fan-coil units.....                    | 279 |
| Owners' Guide To Reducing Air Leakage .....                          | 280 |
| Tracking down leak locations .....                                   | 283 |

## Construction

## 17. Avoiding Mold by Keeping Construction Dry

|  |     |
|--|-----|
| Key Points .....   | 289 |
| Cautions for Each Construction Phase .....                       | 290 |
| Exposed phase - Keep fibrous glass insulation dry.....           | 290 |
| Partially-enclosed - Allow concrete and fireproofing to dry..... | 290 |
| Controlled phase - Watch out for wall board, and for HVAC.....   | 292 |
| How Dry Is Dry Enough To Prevent Mold?.....                      | 294 |
| Measuring Moisture.....  | 296 |
| 1. Electrical Resistance - "Penetrating Meters" .....            | 296 |
| 2. Electrical field variation - "Non-Penetrating Meters" .....   | 298 |
| 3. Equilibrium Relative Humidity (ERH) .....                     | 299 |
| 4. Vapor emission rate - The "Calcium chloride test" .....       | 301 |
| Equipment For Construction Drying.....                           | 302 |
| Construction Drying Techniques.....                              | 302 |
| Specifications To Keep New Construction Dry.....                 | 305 |

## Appendix ..... 308

|  |     |
|--|-----|
| Psychrometric Display - Design vs. Hourly Weather... 308 | 308 |
| Tampa, FL - (I-P units) .....                            | 308 |
| Tampa, FL - (SI units) .....                             | 309 |
| Dehumidification Design Equations.....                   | 310 |
| I-P to SI Conversion Factors .....                       | 311 |
| Dew Point and Humidity Ratio Tables .....                | 312 |
| Psychrometric Charts (showing gr/lb and g/kg).....       | 314 |
| I-P.....   | 314 |
| SI.....  | 315 |
| Book Production Notes.....                               | 316 |