

**FIELD PROCEDURES
MANUAL FOR
UNBONDED
SINGLE STRAND
TENDONS**

3RD EDITION

pti POST-TENSIONING
INSTITUTE

TABLE OF CONTENTS

FIELD PROCEDURES MANUAL FOR
UNBONDED SINGLE STRAND TENDONS

1.0	INTRODUCTION	
1.1	Purpose	1
1.2	Fabrication of Tendons	1
1.3	Responsibilities	1
1.4	Definitions	1
2.0	DOCUMENT CONTROL	
2.1	General	8
2.2	Approved Installation Drawings	8
2.3	Shipping Lists	8
2.4	Material Certifications	8
2.5	Jack Calibrations	9
2.6	Stressing Records	9
3.0	DELIVERY, ACCEPTANCE, HANDLING AND STORAGE	
3.1	Delivery and Acceptance	10
3.2	Handling and Storage	10
4.0	INSTALLATION	
4.1	General	12
4.2	Coordination of all Related Functions	12
4.3	General Installation Procedures	12
4.4	Installation Procedures for One-Way Slabs and Two-Way Flat Plates	13
4.5	Installation Procedures for Beam and Slab	19
4.6	Field Installation of Fixed-Ends	22
4.7	Inspection Checklist Prior to Installation and Placing of Concrete	22
5.0	CONCRETE PLACEMENT	
5.1	General Procedures	24
6.0	TENDON STRESSING	
6.1	General	25
6.2	Preparation for Stressing	25
6.3	Stressing the Tendons	26
6.4	Stressing Slab-on-Ground Tendons	31
6.5	Safety Procedures	32
6.6	Don'ts of Stressing	33
6.7	Inspection Before, During and After Stressing Tendons	34

TABLE OF CONTENTS

FIELD PROCEDURES MANUAL FOR
UNBONDED SINGLE STRAND TENDONS

7.0	ELONGATION		
	7.1	General	35
	7.2	Preparation	35
	7.3	Measurement	36
	7.4	Recording	37
8.0	TENDON FINISHING		
	8.1	General	38
	8.2	Cutting of Tendon Tails	38
	8.3	Grouting of Pocket Former Recesses	38
9.0	ENCAPSULATED SYSTEMS		
	9.1	General	39
	9.2	Purpose and Scope	39
	9.3	Fabrication of Encapsulated Tendons	39
	9.4	Unloading of Encapsulated Tendons	39
	9.5	Job Site Handling of Encapsulated Tendons	39
	9.6	Installation of Encapsulated Systems	40
	9.7	Finishing of Encapsulated System	40
10.0	JOB-SITE TROUBLESHOOTING		
	10.1	“Hazardous” Statement	41
	10.2	Preventing the Most Frequent Problems	41
	10.3	Strand Slippage and/or Jack “Hang Up”	42
	10.4	Honeycomb in Concrete	44
	10.5	Blowouts	44
	10.6	Strand Breakage (one or more wires)	44
	10.7	Tendons too Short to be Stressed Using Normal Stressing Procedures	45
	10.8	Splicing Tendons	46
	10.9	Cracked Wedges	47
	10.10	“Lift-Off” Procedures	48
	10.11	Troubleshooting Monostrand Equipment	48
11.0	APPENDIX		51
	11.1	Example - Material Certification	52
	11.2	Example - Jack Calibration Chart	53
	11.3	Example - Stressing Record Form	54
	11.4	Example - Inspection Checklist	55
	11.5	Example - PTI Plant Certification Tag	60
	11.6	Example - Repair of Damaged Tendons in Aggressive Environments	61