



# CASTINGS PRACTICE

THE 10 RULES OF CASTINGS



JOHN CAMPBELL

# Contents

Dedication	ii		
Preface	vii		
Summary	xi		
<b>Rule 1. Achieve a good quality melt</b>	1		
1.1	Background	1	
1.2	Melting	3	
1.3	Holding	3	
1.4	Pouring	4	
1.5	Melt treatments	5	
1.5.1	Degassing	5	
1.5.2	Additions	6	
1.6	Filtration	7	
1.6.1	Packed beds	7	
1.6.2	Alternative varieties of filters	8	
1.6.3	Practical aspects	8	
<b>Rule 2. Avoid turbulent entrainment (the critical velocity requirement)</b>	9		
2.1	Maximum velocity requirement	10	
2.2	The 'no fall' requirement	13	
2.3	Filling system design	15	
2.3.1	Gravity pouring of open-top moulds	15	
2.3.2	Gravity pouring of closed moulds	16	
2.3.3	Horizontal transfer casting	68	
2.3.4	Counter-gravity	72	
2.3.5	Surface tension controlled filling	75	
2.3.6	Inclusion control: filters and traps	78	
2.3.7	Practical calculation of the filling system	93	
<b>Rule 3. Avoid laminar entrainment of the surface film (the non-stopping, non-reversing condition)</b>	102		
3.1	Continuous expansion of the meniscus	102	
3.2	Arrest of vertical progress	103	
3.3	Waterfall flow	104	
3.4	Horizontal stream flow	104	
3.5	Hesitation and reversal	106	
<b>Rule 4. Avoid bubble damage</b>	108		
4.1	Gravity-filled running systems	111	
4.2	Pumped and low-pressure filling systems	112	
<b>Rule 5. Avoid core blows</b>	114		
5.1	Background	114	
5.2	Prevention	117	
<b>Rule 6. Avoid shrinkage damage</b>	120		
6.1	Feeding systems design background	120	
6.1.1	Gravity feeding	123	
6.1.2	Computer modelling of feeding	124	
6.1.3	Random perturbations to feeding patterns	124	
6.1.4	Dangers of solid feeding	125	
6.1.5	The non-feeding roles of feeders	125	
6.2	The seven feeding rules	126	
Rule 1:	Do not feed	126	
Rule 2:	Heat-transfer requirement	127	
Rule 3:	Mass-transfer requirement	128	
Rule 4:	Junction requirement	132	
Rule 5:	Feed path requirement	133	
Rule 6:	Pressure gradient requirement	138	
Rule 7:	Pressure requirement	140	
The new feeding logic	142		
6.3.1	Background	142	
6.3.2	The new approach	143	
Active feeding	145		
Freezing systems design	146		

6.5.1	External chills	147	10.2.1	Rectilinear systems	177
6.5.2	Internal chills	149	10.2.2	Cylindrical systems	178
6.5.3	Fins	150	10.2.3	Trigonal systems	179
<b>Rule 7. <i>Avoid convection damage</i></b> 157			10.2.4	Thin-walled boxes	179
7.1	Convection: the academic background	157	10.3	Location jigs	180
7.2	Convection: the engineering imperatives	157	10.4	Clamping points	180
7.3	Convection damage and casting section thickness	160	10.5	Mould design: the practical issues	181
7.4	Countering convection	162	10.6	Casting accuracy	182
<b>Rule 8. <i>Reduce segregation damage</i></b> 163			10.7	Tooling accuracy	183
<b>Rule 9. <i>Reduce residual stress (the 'no water quench' requirement)</i></b> 166			10.8	Mould accuracy	183
9.1	Introduction	166	10.9	Summary of factors affecting accuracy	186
9.2	Residual stress from casting	166	10.10	Metrology	186
9.3	Residual stress from quenching	167	<b>Appendix</b> 188		
9.4	Distortion	172	The I.5 factor	188	
9.5	Heat treatment developments	173	The Bernoulli equation	189	
9.6	Epilogue	174	Rate of pour of steel castings from a bottom-pour ladle	191	
<b>Rule 10. <i>Provide location points</i></b> 175			Running system calculation record	191	
10.1	Datums	175	Design methodology for investment castings	194	
10.2	Location points	176	<b>References</b> 195		
			<b>Index</b> 199		