

# **Contents**

Introduction	xviii
<b>Chapter 1    CLI Usage    1</b>	
1-1: Cisco Internetwork Operating System (IOS) Software	1
Using Cisco IOS Software	2
1-2: ROM Monitor	9
Using the ROM Monitor Command Set	9
<b>Chapter 2    Switch Functionality    13</b>	
2-1: Catalyst Switch Families	13
Catalyst 2000 Series	13
Catalyst 3000 Series	14
Catalyst 4500 Series	15
Catalyst 6500	16
2-2: Switched Campus Network Designs	17
Catalyst Switch Families	23
Cisco Validated Designs: Campus	23
<b>Chapter 3    Supervisor Engine Configuration    25</b>	
3-1: Prompts and Banners	25
Configuration of Prompt	26
Configuration of Banner	26
Feature Example	26
3-2: IP Addressing and Services	27
Configuring an IP Management Address	27
Configuring a Default Gateway	28
Setting Up DNS Services or Host Tables	28
Configuring HTTP Services	29
Feature Example	29
3-3: Passwords and Password Recovery	30
Configuration of Passwords	30
Feature Example	30
Password Recovery: Procedure 1	31
Feature Example	32
Password Recovery on IOS Devices: Procedure 2	33
Feature Example	33

3-4: Managing Modules	34
Viewing Modules	34
Accessing Modules	34
Resetting Modules	34
Powering Modules Up and Down	35
3-5: File Management and Boot Parameters	35
Navigating File Systems	36
Deleting Files from Flash	38
Copying System Files	39
File System Boot Parameters	40
Alias Commands	41
3-6: Redundant Supervisors	42
Forcing a Change to the Standby Supervisor	43
Synchronizing IOS Images	44
Synchronizing Boot Parameters	45
3-7: Cisco Discovery Protocol	46
Configuration of CDP	46
Feature Example	47
3-8: Time and Calendar	47
System Time Configuration	48
<i>Setting the System Time Manually</i>	48
<i>Setting the System Time Through NTP</i>	49
Example	50

**Chapter 4     Layer 2 Interface Configuration   53**

4-1: Switching Table	53
Configuration	53
Displaying Information About the Switching Table	54
Switching Table Example	54
4-2: Port Selection	56
Configuration	56
Port Selection Example	57
4-3: Ethernet	57
Configuration	57
Ethernet Example	60
Displaying Information About Layer 2 Interfaces	61

4-4: EtherChannel	62
Configuration	63
EtherChannel Example	67
Displaying Information About EtherChannels	68

## **Chapter 5    Layer 3 Interface Configuration  71**

5-1: Layer 3 Switching	71
5-2: Layer 3 Ethernet Interfaces	72
Configuration	72
Verifying the Configuration	73
Feature Example	73
5-3: Layer 3 EtherChannels	74
Configuration	74
Verifying the Channel	76
Feature Example	77
5-4: WAN Interfaces	78
Configuration	78
Configuring an Enhanced FlexWAN Interface	78
Configuring a SPA Interface Processor (SIP) / Shared Port Adapter (SPA) WAN Interface	79
Configuring a Packet-over-SONET Interface	80
Verifying Configurations	81
Feature Example	81
5-5: Layer 3 Virtual Interfaces	82
Configuring a VLAN Interface	82
Configuring Subinterfaces	83
Verifying Configurations	84
Feature Example	84
5-6: Routing Tables	85
Configuration	85
Verifying Routes	86

## **Chapter 6    VLANs and Trunking  87**

6-1: VLAN Configuration	87
Creation of an Ethernet VLAN	88
Feature Example	90

6-2: VLAN Port Assignments	91
Configuring Static VLANs	91
Configuring Dynamic VLANs	91
Verifying VLAN Assignments	93
6-3: Trunking	93
Enabling Trunking	93
Specifying VLANs to Trunk	96
Verifying Trunks	97
Feature Example	97
6-4: VLAN Trunking Protocol	98
Enabling VTP for Operation	98
Setting VTP Passwords	99
Changing VTP Modes	100
Enabling VTP Pruning	101
Changing VTP Versions	102
Verifying VTP Operation	102
Feature Example	103
6-5: Private VLANs	104
Configuring Private VLANs	105
Configuring Private Edge VLANs	106
Verifying Private VLAN Operation	107
Feature Example	107

## **Chapter 7    Spanning Tree Protocol (STP)    111**

7-1: STP Operation	111
STP Process	112
STP Tiebreakers	113
Path Costs	113
STP Port States	114
STP Topology Changes	114
Improving STP Stability	115
STP Operation Example	115
7-2: STP Configuration	116
Displaying Information About STP	120
STP Configuration Examples	120
<i>Poor STP Root Placement</i>	120
<i>STP Load Balancing</i>	122

7-3: STP Convergence Tuning	124
Configuring STP Convergence Tuning	125
7-4: Navigating the Spanning-Tree Topology	126
<b>Chapter 8    Configuring High Availability Features</b>	<b>131</b>
8-1: Route Processor Redundancy (RPR/RPR+)	131
Configuration	132
Displaying Information About RPR	132
8-2: Non-Stop Forwarding/Supervisor Switchover (NSF/SSO) with Supervisor Redundancy	132
SSO/NSF Configuration	133
Displaying Information About SSO and NSF	135
8-3: Router Redundancy with HSRP	135
Configuration	136
HSRP Example	137
Displaying Information About HSRP	138
8-4: Fast Software Upgrade (FSU) and Enhanced Fast Software Upgrade (eFSU)	138
<b>Chapter 9    Multicast</b>	<b>141</b>
9-1: Multicast Addressing	141
9-2: IGMP Snooping	142
Configuration	143
IGMP Snooping Example	144
Displaying Information About IGMP Snooping	145
<b>Chapter 10    Server Load Balancing (SLB)</b>	<b>147</b>
10-1: SLB	147
Configuration	149
SLB Example	155
Displaying Information About SLB	157
10-2: SLB Firewall Load Balancing	158
Configuration	159
Firewall Load-Balancing Example	161
Displaying Information About Firewall Load Balancing	164
10-3: SLB Probes	164
Configuration	165
Displaying Information About SLB Probes	166

**Chapter 11 Controlling Traffic and Switch Access 167**

- 11-1: Broadcast Suppression 168
  - Configuring Broadcast Suppression 168
  - Verifying Configuration 170
  - Feature Example 170
- 11-2: Protocol Filtering 170
  - Configuration 171
  - Verification 171
  - Feature Example 172
- 11-3: Port Security 173
  - Configuration 173
  - Verification 175
  - Feature Example 175
- 11-4: VLAN Access Control Lists 175
  - IOS VACL Configuration 176
  - Verification 178
  - Feature Example 178
- 11-5: Switch Authentication 180
  - Configuration 180
  - Verification 182
  - Feature Example 182
- 11-6: Access Class 183
  - Configuration 183
  - Verification 184
  - Feature Example 184
- 11-7: SSH Telnet Configuration 184
  - Configuration 184
  - Verification 185
  - Feature Example 185
- 11-8: 802.1X Port Authentication 185
  - Configuration 186
  - Feature Example 186
- 11-9: Layer 2 Security 186
  - Port Security 188
  - Feature Example 188
  - Verification 188

DHCP Snooping	189
Feature Example	189
Verification	190
Dynamic ARP Inspection	191
Feature Example	191
Verification	192

## **Chapter 12 Switch Management 193**

12-1: Logging	193
Configuration	194
Logging Example	198
Displaying Information About Logging	198
12-2: Simple Network Management Protocol	198
Configuration	199
SNMP Example	205
Displaying Information About SNMP	206
12-3: Switched Port Analyzer	206
SPAN Configuration	206
RSPAN Configuration	208
SPAN Examples	210
Displaying Information About SPAN	211
12-4: Power Management	213
Configuration	213
Displaying Information About Power Management	214
12-5: Environmental Monitoring	214
12-6: Packet Tracing	214
Configuration	215
Packet-Tracing Example	218

## **Chapter 13 Quality of Service 221**

13-1: QoS Theory	221
Layer 2 QoS Classification and Marking	222
Layer 3 QoS Classification and Marking	223
Catalyst Switch Queuing	226
13-2: QoS Configuration	226
Catalyst 2000/3000 Configuration	228
All Other Catalyst Configuration	228
Displaying Information About QoS	245

# Cisco LAN Switching Configuration Handbook

13-3: QoS Data Export	246
Configuration	246
QoS Data Export Example	248
Displaying Information About QoS Data Export	248

## **Chapter 14 Voice 249**

14-1: Voice Ports	249
Configuration	250
Example	253
Displaying Information About Voice Ports	253
14-2: Voice QoS	254
Access Layer Configuration	256
Distribution and Core Layer Configuration	259
Voice QoS Example	261

## **Appendix A Cabling Quick Reference 263**

Back-to-Back Connections	267
Ethernet Connections	267
Asynchronous Serial Connections	268
T1/E1 CSU/DSU Connections	269

## **Appendix B Well-known Protocol, Port, and Other Numbers 271**

Index	317
-------	-----