




mobile communications series

Zerihun Abate

WiMAX RF SYSTEMS ENGINEERING



Contents

	Preface	<i>xvii</i>
	Part I: Introduction	1
1	Introduction	3
1.1	WiMAX System	4
1.2	WiMAX and Related Standards	6
1.2.1	WiMAX 802.16d (802.16-2004)	6
1.2.2	WiMAX 802.16e (802.16-2005)	8
1.2.3	WiMAX 802.16/d/e and Related Standards Summary	8
1.2.4	Upcoming 802.16m Standard	8
1.3	Range and Spectrum Efficiency Summary	10
1.4	WiMAX Spectrum Worldwide	11
1.5	What Is OFDM?	11
1.6	The Key Features of WiMAX	11
1.6.1	Intersymbol Interference (ISI)	12
1.6.2	Frequency Selective Fading	13
1.6.3	Adaptive Modulation and Coding (AMC)	14
1.6.4	Very High Data Rate	14

1.6.5	Delay Versus Doppler Spreads and Frequency Diversity	15
1.7	WiMAX Transceiver	15
1.8	OFDM Signal Generation	15
1.9	OFDM Challenges and Mitigations	16
	References	18
2	<u>OFDM Flavors, ISI, Doppler, Rayleigh, and Fading</u>	19
2.1	OFDM Flavors	19
2.2	Subchannelization	21
2.3	Scalable OFDMA, Doppler Shift, and ISI	22
2.3.1	Doppler Spread	23
2.4	Coherence Bandwidth	23
2.5	ISI, Delay, and Fading	24
2.5.1	Selective Frequency Fading Derivation	25
2.5.2	Frequency-Selective Fading and Flat Fading	26
2.5.3	Rayleigh Fading Simulator	29
2.5.4	Fade Rate and Doppler Effect—Slow Fading and Fast Fading Spread	30
	References	32
	<u>Part II: Technical Background</u>	33
3	<u>Modulation</u>	35
3.1	Overview	35
3.2	Digital Modulation (Representing Digital Bits with Analog Signals)	36
3.3	Encoding and Decoding Phase Information	40
3.4	Quadrature Amplitude Modulation	44
3.5	Multicarrier Modulation Transmissions and OFDM	46
3.6	Adaptive Modulation and Coding (AMC)	48
	References	48

4	<u>RF Propagations, Measurements, and Models</u>	49
4.1	RF Propagation	49
4.1.1	Cell Site Definitions	49
4.1.2	Free Space Path Loss	50
4.1.3	Confidence Level	51
4.1.4	Confidence Interval	53
4.2	Measurements and Drive Test Considerations	54
4.3	Propagation Models	57
4.3.1	Free Space Path Loss Model	59
4.3.2	The Okumura-Hata Model	60
4.3.3	PCS Extension to the Hata Model	61
4.3.4	Longely-Rice Model	62
4.3.5	Indoor Propagation Model	62
	References	64
5	<u>Communication Channel Characterization</u>	65
5.1	Gaussian Noise and Line-of-Sight and Nonline-of-Sight Paths	65
5.2	Characterizing the Radio Environment	65
5.3	Multipaths and Doppler Shifts	68
5.4	Nyquist and Shannon-Hartley	72
5.4.1	Noise, Noise Floor, and Interference Definitions	72
5.4.2	Nyquist Minimum Bandwidth	73
5.4.2	Shannon-Hartley	73
5.5	Separation of Colocated Antennas	75
5.5.1	Vertical and Horizontal Separation	75
5.6	Intermodulation	77
5.6.1	Strategies to Avoid, Troubleshoot, and Mitigate IM	78
5.7	WiMAX Versus Satellite Interference Consideration [5]	80
5.8	Interferences	81
5.8.1	Adjacent Channel Interference	81
5.8.2	Distance Path Loss of Geographic Separation	81
5.8.3	Near-End-Far-End	81

5.8.4	Antenna Directions	82
5.9	<i>Other Sources of Signal Losses</i>	82
5.10	Tower-Mounted Amplifiers (TMAs)	83
	References	85
Part III: WiMAX Radio Design		87
6	Network Planning Fundamentals	89
6.1	WiMAX Link Budget	89
6.2	Propagation Model and Range Calculation	93
6.2.1	Prediction and Simulation	93
6.3	Stanford University Interim Model (SUI Model)	94
6.4	Coverage and Capacity Planning	98
6.4.1	Capacity Considerations	100
6.5	Investment and Break-Even Considerations	100
	References	101
7	Point-to-Point Link Design	103
7.1	Introduction	103
7.2	Bandwidths, Rainfalls, and Margins	104
7.3	PTP Design Parameters and Signal Impairments	107
7.3.1	Refractivity	107
7.3.2	Foliage Attenuation	107
7.4	Availability	108
7.4.1	Path Availability	108
7.5	PTP Design Examples	109
7.5.1	Design 1	109
7.5.2	Design 2	110
	References	112
8	Link, Design, Oversubscription, and Delay	113
8.1	Link Analysis and Design	113

8.1.1	Digital Communication Link Design Example	113
8.1.2	WiMAX Link Design Examples	115
8.1.3	Cochannel Interference and C/I Computation Example	119
8.2	Oversubscription, Link Usage, and Delay	120
8.2.1	Link Usage	120
8.2.2	Delay	121
8.2.3	Poisson Arrival Process	121
8.2.4	Erlang B	123
8.2.5	Erlang C (Blocked Calls Queued)	125
	References	128
9	WiMAX Capacity, Frequency Planning, and MIMO Antennas	129
9.1	WiMAX Capacity	129
9.1.1	Capacity Calculation	130
9.2	WiMAX Frequency Planning	133
9.2.1	Fractional Frequency Reuse	135
9.2.2	Frequency Plan (Other Schemes)	136
9.3	MIMO Antennas	136
9.3.1	Overview	136
9.3.2	Terms and Concepts	138
9.3.3	Open Loop MIMO	140
9.3.4	Beam Forming	141
9.3.5	MIMO Antenna Concept	141
9.3.6	Summary of Major Antenna Techniques	144
	References	144
10	Case Study	145
10.1	Range Determination	145
10.1.1	Assumptions	146
10.1.2	Range Calculation	147
10.2	Number of Sites for Coverage and Capacity	151
10.3	Summary	151

11	Preliminary Design to Benchmarking	157
11.1	Overview	157
11.2	Back-of-the-Envelope Link Budget and Area Estimate	158
11.3	Reverse Engineering	160
11.4	Model Tuning	161
11.5	Model Tuning Using a Prediction Tool	163
11.6	Site Design Using a Prediction Tool	164
11.7	Site Qualification	167
11.8	The Use of Planning Tools	167
11.9	Site Construction	169
11.10	Optimization	170
11.11	Expansion and Quality Improvement of a Network	172
11.12	Benchmarking	172

	Part IV: Network and Security	177
--	--------------------------------------	------------

12	Fundamentals of WiMAX Network	179
12.1	Introduction	179
12.2	OSI Models and IP-Based Networks	180
12.2.1	PHY Layer	182
12.2.2	Data Link Layer	182
12.2.3	Network Layer	182
12.2.4	Transport Layer	182
12.2.5	Application Layer	182
12.2.6	A Router	182
12.2.7	A Bridge	183
12.3	WiMAX Architecture	184
12.3.1	ASN	184
12.3.2	CSN	185
12.3.3	WiMAX Protocol Stack	187
12.3.4	MAC and QoS	188

12.3.5	Scheduling	190
12.3.6	QoS Protocols	190
12.3.7	Session Protocol	191
12.4	WiMAX Frame Structures	192
12.4.1	TDD Virtues	192
12.4.2	OFDMA TDD Frame Structure	193
12.4.3	Subchannels, Slots, Frames, and Permutation	194
12.5	Introduction to VoIP	195
12.6	VoIP over WiMAX	197
	References	199

13 WiMAX Security **201**

13.1	Introduction	201
13.2	Documents Related to the WiMAX Security Standard	202
13.3	Fundamental Data Encryption Techniques	202
13.4	Typical Security Concerns	203
13.5	Accessing Service	203
13.6	Authentication	204
13.7	Authorization	206
13.8	The Network Side of Security	206
13.9	Security Characterization in WiMAX	207
13.10	Security Challenges	208
13.10.1	PHY Layer Protection	208
13.11	MAC Layer Protection	209
	References	210

Part V: Comparable Systems **211**

14 WiFi Radio Planning **213**

14.1	Overview	213
14.2	Channel and Band Assignments	214

14.3	FCC Power Requirements	215
14.4	Link Budget	217
14.5	The Biggest Recorded Range	218
14.6	Coverage	219
14.7	Capacity	221
14.8	Security Gaps and Solutions	224
14.8.1	IEEE 802.1x	224
14.8.2	802.1x Authentication Steps	226
14.8.3	The Significance of EAP	227
	References	227
15	UMTS and WiMAX Comparison	229
15.1	Overview	229
15.2	GSM-to-UMTS Evolution	232
15.2.1	Key Component Definitions	235
15.3	UMTS Architecture's Similarities with WiMAX	236
15.4	Physical Layer Specifications	236
15.5	WCDMA Physical Layer Radio Frame	238
15.6	Channel Definitions and Functions	239
15.6.1	Uplink and Downlink Channels in WCDMA	239
15.6.2	Channel Mappings	243
15.6.3	Essentials of UE-Node B Air Interface Communication	243
15.7	Channelization and Spreading	245
15.7.1	Spreading and Scrambling Codes	245
15.8	Typical Link Budget	247
15.9	Typical Capacity	250
15.9.1	HSDPA Capacity	250
	References	250
16	Competing with and Complementing WiMAX	251
16.1	Signaling System 7	252

16.1.1	ANSI-41	252
16.1.2	Protocol	253
16.1.3	ISUP	255
16.1.4	SS7 Network	255
16.2	Wireless Failover Alternative for SS7	256
16.3	WiMAX Backhaul for WiFi Mesh	256
16.4	WiMAX Complementing WiFi Hotspot	258
16.5	Working with IP-Based Technologies	259
16.6	Versatility of WiMAX Network and Protocol	260
16.7	Competing Against WiMAX	263
16.7.1	Overview	263
16.7.2	Long-Term Evolution (LTE)	265
16.7.3	Comments and Opinions on UMB and WiMAX	266
16.8	The Competition for Dominance	267
	References	268
Appendix A		271
Appendix B		275
Appendix C		279
Appendix D		287
Acronyms		291
About the Author		301
Index		303