

JAMES D. HALDERMAN SIXTH EDITION

# DIAGNOSIS AND TROUBLESHOOTING OF AUTOMOTIVE ELECTRICAL, ELECTRONIC, AND COMPUTER SYSTEMS



PROFESSIONAL TECHNICIAN SERIES

# BRIEF CONTENTS

---

<b>chapter 1</b>	<b>Service Information, Tools, and Safety</b>	<b>1</b>
<b>chapter 2</b>	<b>Environmental and Hazardous Materials</b>	<b>35</b>
<b>chapter 3</b>	<b>Electrical Fundamentals</b>	<b>46</b>
<b>chapter 4</b>	<b>Electrical Circuits and Ohm's Law</b>	<b>56</b>
<b>chapter 5</b>	<b>Series, Parallel, and Series-Parallel Circuits</b>	<b>63</b>
<b>chapter 6</b>	<b>Circuit Testers and Digital Meters</b>	<b>76</b>
<b>chapter 7</b>	<b>Oscilloscopes and Graphing Multimeters</b>	<b>94</b>
<b>chapter 8</b>	<b>Automotive Wiring and Wire Repair</b>	<b>102</b>
<b>chapter 9</b>	<b>Wiring Schematics and Circuit Testing</b>	<b>116</b>
<b>chapter 10</b>	<b>Capacitance and Capacitors</b>	<b>133</b>
<b>chapter 11</b>	<b>Magnetism and Electromagnetism</b>	<b>139</b>
<b>chapter 12</b>	<b>Electronic Fundamentals</b>	<b>152</b>
<b>chapter 13</b>	<b>Computer Fundamentals</b>	<b>169</b>
<b>chapter 14</b>	<b>CAN and Network Communications</b>	<b>177</b>
<b>chapter 15</b>	<b>Batteries</b>	<b>194</b>
<b>chapter 16</b>	<b>Battery Testing and Service</b>	<b>202</b>
<b>chapter 17</b>	<b>Cranking System</b>	<b>216</b>
<b>chapter 18</b>	<b>Cranking System Diagnosis and Service</b>	<b>228</b>
<b>chapter 19</b>	<b>Charging System</b>	<b>242</b>
<b>chapter 20</b>	<b>Charging System Diagnosis and Service</b>	<b>254</b>
<b>chapter 21</b>	<b>Lighting and Signaling Circuits</b>	<b>274</b>
<b>chapter 22</b>	<b>Driver Information and Navigation Systems</b>	<b>297</b>
<b>chapter 23</b>	<b>Horn, Wiper, and Blower Motor Circuits</b>	<b>322</b>
<b>chapter 24</b>	<b>Accessory Circuits</b>	<b>336</b>
<b>chapter 25</b>	<b>Airbag and Pretensioner Circuits</b>	<b>370</b>
<b>chapter 26</b>	<b>Audio System Operation and Diagnosis</b>	<b>384</b>
<b>chapter 27</b>	<b>On-Board Diagnosis</b>	<b>400</b>

<b>chapter 28</b>	<b>Temperature Sensors</b>	<b>409</b>
<b>chapter 29</b>	<b>Throttle Position (TP) Sensors</b>	<b>420</b>
<b>chapter 30</b>	<b>MAP/BARO Sensors</b>	<b>426</b>
<b>chapter 31</b>	<b>Mass Air Flow Sensors</b>	<b>435</b>
<b>chapter 32</b>	<b>Oxygen Sensors</b>	<b>442</b>
<b>chapter 33</b>	<b>Ignition System Operation and Diagnosis</b>	<b>459</b>
<b>chapter 34</b>	<b>Fuel Pumps, Lines, and Filters</b>	<b>483</b>
<b>chapter 35</b>	<b>Fuel-Injection Components and Operation</b>	<b>501</b>
<b>chapter 36</b>	<b>Electronic Throttle Control System</b>	<b>515</b>
<b>chapter 37</b>	<b>Fuel-Injection System Diagnosis and Service</b>	<b>524</b>
<b>chapter 38</b>	<b>Vehicle Emission Standards and Testing</b>	<b>544</b>
<b>chapter 39</b>	<b>Emission Control Devices Operation and Diagnosis</b>	<b>555</b>
<b>chapter 40</b>	<b>Scan Tools and Engine Performance Diagnosis</b>	<b>583</b>
<b>chapter 41</b>	<b>Hybrid Safety and Service Procedures</b>	<b>602</b>
<b>chapter 42</b>	<b>Fuel Cells and Advanced Technologies</b>	<b>616</b>
<b>appendix 1</b>	<b>Electrical/Electronic Systems (A6)</b>	<b>631</b>
<b>appendix 2</b>	<b>Engine Performance (A8)</b>	<b>634</b>
	<b>English Glossary</b>	<b>636</b>
	<b>Spanish Glossary</b>	<b>647</b>
	<b>Index</b>	<b>660</b>