

# Automotive Mechanics VOL-2

Ed May

**7th**  
EDITION

Preface	xiii
Acknowledgments	xiv

## Part 1 • Engine construction and overhaul

<b>1 The engine assembly</b>	<b>3</b>	Servicing rocker-arm assemblies	60
The engine assembly	4	Servicing hydraulic lifters and lash adjusters	60
Engine components	4	Valve refacers and refacing	62
V-type engine assembly	9	Valve-seat reconditioning	63
Engine systems	9	Valve-seat cutters	65
Engine configurations	12	Servicing valve guides	66
Cylinder arrangements	14	Servicing valve-seat inserts	68
Engine design features	16	Camshaft service	69
Automotive engines	18	<i>Technical terms</i>	71
<i>Technical terms</i>	18	<i>Review questions</i>	71
<i>Review questions</i>	19		
<b>2 Cylinder head and valves</b>	<b>21</b>	<b>4 Cylinder block, crankshaft and bearings</b>	<b>73</b>
Cylinder heads	22	Cylinder blocks	74
Combustion chambers	24	Cylinder-block construction	75
Engine valves	26	Cylinder sleeves	77
Valve trains for OHV engines	30	Cylinder surface-finish	78
Hydraulic valve lifters for OHV engines	31	Crankshafts	79
Valve trains for OHC engines	32	Crankshaft bearings	81
Hydraulic lash adjusters for OHC engines	33	Cylinder block and crankcase design	84
Camshafts	34	Engine vibration and balance	84
Camshaft drives and timing	35	Balance of reciprocating parts	87
Drives for DOHC	39	Balance shafts	88
Tensioners and dampers	40	<i>Technical terms</i>	88
Variable valve timing	41	<i>Review questions</i>	88
Valve-timing diagram	44		
Engine illustrations	45	<b>5 Cylinder-block, crankshaft and bearing service</b>	<b>91</b>
<i>Technical terms</i>	45	Servicing cylinder blocks	92
<i>Review questions</i>	46	Checking and measuring cylinders	93
<b>3 Cylinder-head and valve service</b>	<b>49</b>	Hones and honing cylinders	95
Cylinder-head service	50	Reboring cylinders	97
Dismantling the valve mechanism	51	Servicing cylinder sleeves	98
Removing and dismantling cylinder heads	53	Crankshaft service	100
Installing cylinder heads	55	Servicing main bearings	101
Valve-clearance adjustments	57	Analysing bearing failures	105
Servicing valves and springs	58	<i>Technical terms</i>	107
		<i>Review questions</i>	107

<b>6 Pistons, connecting rods and bearings</b>	<b>109</b>	<b>10 Rotary engine</b>	<b>163</b>
Pistons	110	Basic rotary engine	164
Control of piston temperature	111	Parts of the rotary engine	164
Piston designs	113	Engine strokes	166
Piston rings	114	Engine operation	167
Piston-ring sets	116	Construction of a rotary engine	168
Piston pins	117	Cooling system	171
Connecting rods	118	Lubricating system	173
Forces in a connecting-rod assembly	119	Intake and exhaust systems	174
Connecting-rod bearings	120	Fuel system	174
<i>Technical terms</i>	120	Ignition system	175
<i>Review questions</i>	120	Engine assembly	175
<b>7 Piston, connecting-rod and bearing service</b>	<b>121</b>	Service requirements	176
Dismantling the piston assembly	122	<i>Technical terms</i>	178
Removing and replacing piston pins	122	<i>Review questions</i>	178
Piston measurement and clearance	124		
Fitting piston rings	126	<b>Part 2 · Fuel and engine management</b>	
Installing rings on a piston	127	<b>11 Carburettors</b>	<b>183</b>
Installing pistons in cylinders	127	Basic carburettors	184
Installing connecting-rod bearings	128	Carburettor systems	184
Checking connecting-rod bearings	129	Carburettor construction	185
Connecting-rod alignment	130	Single-barrel and multibarrel carburettors	186
Analysing piston, ring and cylinder problems	131	Two-stage carburettor operation	186
<i>Technical terms</i>	133	Throttle-valve operation	191
<i>Review questions</i>	133	Mixture correction	193
<b>8 General engine service</b>	<b>135</b>	Automatic chokes	195
Reasons for dismantling an engine	136	Manual chokes	198
Types of engine work	136	Other carburettor components	198
Sequence of engine work	138	<i>Technical terms</i>	200
Diagnosing and checking	138	<i>Review questions</i>	201
Dismantling procedure	140	<b>12 Carburettor service</b>	<b>203</b>
Cleaning and inspecting	140	Checking linkages and controls	204
Taking measurements	143	Automatic chokes	205
Working with bolts and fasteners	145	General carburettor checks	206
Reconditioning or renewing parts	148	Idle adjustments	207
Reassembling and adjusting	148	Carburettor components	209
Finalising and checking	149	Major carburettor service	209
<i>Technical terms</i>	150	Dismantling a carburettor	211
<i>Review questions</i>	150	Cleaning and inspecting	212
<b>9 Engine measurement and performance</b>	<b>153</b>	Reassembling a carburettor	213
Basic terms and definitions	154	Removing and installing a carburettor	213
Engine terms and definitions	155	Carburettor problems	214
Engine power	156	<i>Technical terms</i>	215
Engine torque and power	158	<i>Review questions</i>	215
Engine efficiency	159	<b>13 Electronic fuel injection and engine management</b>	<b>217</b>
Performance ratings	160	Basic principles of EFI	218
<i>Technical terms</i>	161	Types of EFI systems	218
<i>Review questions</i>	161		



Block diagrams of an EFI system	220	16 Induction systems, turbochargers and superchargers	299
Operation of a multipoint EFI system	222	Engine design features	300
Components of an EFI system	224	Turbocharging and supercharging	301
Engine management	229	Turbochargers	301
Electronic concentrated control system	231	Turbocharger construction and operation	303
Sequential multipoint fuel injection system	234	Turbocharger control	304
Other features of engine control systems	235	Twin-scroll turbocharger	307
Throttle-body injection (TBI)	241	Intercooler	307
Servicing engine control systems	242	Operating a turbocharged engine	309
Locating basic faults	244	Service requirements for turbochargers	309
Fault diagnosis	245	Superchargers	309
Testing equipment	246	Supercharger construction and operation	310
<i>Technical terms</i>	248	Supercharger control	311
<i>Review questions</i>	248	Service requirements for superchargers	313
14 Ignition systems	249	Supercharger installation	313
Ignition system components and their function	250	<i>Technical terms</i>	313
Types of ignition systems	254	<i>Review questions</i>	314
Breaker ignition systems	255	17 Maintenance and diagnosis:	
Electronic ignition systems	256	petrol engines	317
Direct ignition systems	259	Maintenance	318
Coil-on-plug ignition systems	262	Diagnosing problems	319
Integrated ignition systems	263	Diagnosis chart	319
Ignition timing	264	EFI system diagnosis	324
Ignition service – general	267	Engine noises	325
Spark plug service	267	Engine analysis and tune-up equipment	327
Distributor service	269	Engine analyser ignition display	327
Fault diagnosis	271	Connecting the engine analyser to the engine	331
Diagnostic equipment	273	Display patterns for ignition conditions	331
<i>Technical terms</i>	273	Electronic ignition and EFI patterns	332
<i>Review questions</i>	274	Scan tools	333
15 Emission controls	277	Exhaust-gas analyser	334
Motor vehicle pollution: sources	278	Meters and gauges	334
Evaporative-control system	278	Electrical measuring instruments	337
Crankcase ventilation	281	<i>Technical terms</i>	338
Exhaust emissions	282	<i>Review questions</i>	338
Catalytic converters	283	Part 3 - Diesel engines	
Engine management	284	18 Diesel engines: features	341
Engine design	286	Comparison of diesel and petrol engines	342
Carburettor engines: emission systems	288	Four-stroke diesel engines	342
Other emission-system devices	291	Two-stroke diesel engines	342
Emission standards	292	Scavenging	345
Servicing emission controls	293	Types of combustion chambers	345
Diagnosis guides	295	Combustion chambers	346
<i>Technical terms</i>	297	Devices to assist starting	348
<i>Review questions</i>	297	Combustion of fuel in the engine	349
		Turbochargers and blowers	351

Turbocharged diesel engines	352	Torque converter construction	414
Other engine design features	352	Torque converter operation	415
<i>Technical terms</i>	354	Torque multiplication	417
<i>Review questions</i>	355	Stator and one-way clutch action	417
<b>19 Diesel fuel systems</b>	357	Lock-up torque converters	418
Diesel fuel systems: general	358	<i>Technical terms</i>	419
Fuel injection systems	359	<i>Review questions</i>	421
Fuel supply pumps	361	<b>22 Automatic transmissions: mechanical</b>	423
Fuel filters	363	Transmission and transaxle arrangements	424
Injectors	365	Planetary gears	424
Types of injectors	366	Simplified planetary gear operation	426
Distributor injection pumps: axial type	369	Compound planetary gears	427
Governor for axial pumps	371	Transmission with compound planetary gears	428
Complete axial distributor pump	373	Power flow in compound planetary gearing	429
Distributor injector pumps: radial type	373	Planetary gears with a common sun gear	431
Radial pump schematic: operation	375	Transaxle gearing with a common sun gear	433
Common-rail injection systems	376	Four-speed transmissions	435
Injectors for common-rail systems	380	Four-speed automatic transmission with compound planetary gears	436
Basic in-line injection pumps	382	Four-speed automatic transaxle with compound planetary gears	438
In-line pump construction	383	Transaxle with helical gears	439
In-line pump installation	384	Complete automatic transaxles	441
Electronic diesel control	384	Continuously variable transaxle (CVT)	442
Injection pumps with electronic control	386	<i>Technical terms</i>	446
<i>Technical terms</i>	387	<i>Review questions</i>	446
<i>Review questions</i>	387	<b>23 Automatic transmissions: hydraulics and controls</b>	449
<b>20 Diesel fuel system service</b>	389	Automatic transmission control	450
Servicing fuel filters	390	Simple hydraulic system	451
Bleeding and checking the fuel system	391	Hydraulic system components	452
Injector service	392	Hydraulic valve operation	453
Removing and installing injectors	393	Hydraulic system diagram	455
Servicing injectors	394	System components: oil pumps	455
Injector testing	397	Hydraulic system: valves	457
Injector faults	398	Hydraulic system: governors	460
Removing and installing injection pumps	398	Hydraulic actuators	462
Spill-timing an in-line pump	401	Hydraulic-circuit diagrams	463
Injection pump servicing	402	Electronic control of transmission	466
Diesel engine problems	404	Electronic control systems	468
Checking diesel electronic controls	406	Location of electronic components	472
<i>Technical terms</i>	406	Solenoid-operated shifts	472
<i>Review questions</i>	407	Electronic control of converter clutch	473
<b>Part 4 • Automatic transmissions and drive</b>		Determining shift points	474
<b>21 Automatic transmissions: torque converters</b>	411	Adaptive shift strategy	475
Automatic transmissions and transaxles	412	Adaptive controls	476
Hydraulic couplings	413	<i>Technical terms</i>	477
		<i>Review questions</i>	477

<b>24 Automatic transmission service</b>	<b>479</b>	<b>27 Charging system</b>	<b>551</b>
Maintenance	480	The charging system	552
Checking and changing the fluid	480	Generating principles	552
Automatic transmission fluids	482	Simple alternator	554
Fluid problems	484	Changing ac to dc (rectification)	555
Extra cooling and filtering	485	Alternator construction	556
Transmission adjustments	486	Rectification and diodes	558
Brake band adjustments	490	Voltage regulation	559
Fault diagnosis and checks	491	Alternator and regulator circuit	561
Road testing	493	Vibrating-contact regulator	563
Diagnosing problems	496	Servicing the charging system	564
Transmission overhaul	499	Alternator checks	565
Transmission construction	499	Alternator service	566
<i>Technical terms</i>	500	Regulator service	568
<i>Review questions</i>	501	Charging-system problems	569
		<i>Technical terms</i>	569
		<i>Review questions</i>	570
<b>25 Four-wheel drive and all-wheel drive</b>	<b>505</b>	<b>28 Body-electrical systems</b>	<b>571</b>
Drive-line arrangements	506	Wiring systems	572
Transmission with gear transfer	507	Wiring harness	573
Transfer case with chain drive	510	Electrical circuit diagrams	574
Centre differentials	514	Electrical symbols and circuits	578
Transaxle centre differentials	514	Electrical circuit components	579
Viscous couplings	514	Fuses and fusible links	581
Transfer unit with chain and viscous coupling	516	Fuse and relay locations	583
Suspension arrangements	519	Lamps and bulbs	584
Four-wheel-drive service	521	Headlamps	585
All-wheel drive	524	Exterior and interior lamps	587
Types of all-wheel-drive systems	524	Body electronic module (BEM): overview	589
<i>Technical terms</i>	530	CAN bus system	591
<i>Review questions</i>	530	<i>Technical terms</i>	592
		<i>Review questions</i>	593
<b>Part 5 • Electrical systems</b>		<b>29 Body-electrical service</b>	<b>595</b>
<b>26 Starting system</b>	<b>533</b>	Replacing bulbs	596
Basic starter motor	534	Headlamp aiming	597
Basic motor principles	535	Replacing exterior and interior bulbs	599
Starter motor operation	536	Fitting accessories and making connections	601
Starter motor characteristics	537	Trailer electrical connections	602
Direct-drive starters	538	Servicing harnesses and connectors	603
Reduction-type starters	539	Checking fuses and fusible links	603
Starting electrical system	539	Checking relays	605
Removing and installing starters	541	Basic electrical faults	605
Dismantling starters	542	Electrical circuit faults	606
Cleaning and testing	543	Locating faults in circuits	607
Starter circuit checks	545	General circuit checks	610
Bench tests	546	Precautions with electronic components	610
Flywheel ring gear	546	Use of test instruments	611
Starter problems	547	<i>Technical terms</i>	612
Starter construction	547	<i>Review questions</i>	612
<i>Technical terms</i>	548		
<i>Review questions</i>	548		

<b>30 Instruments and indicators</b>	615	High- and low-pressure sides	669
Instrument panel	616	System components	670
Instrument panel construction	616	Refrigerant and compressor oil	676
Instruments with magnetic operation	618	Air-conditioner controls	677
Instruments with thermal operation	621	Air-conditioner electrical circuit	678
Mechanical gauges	622	Automatic climate control	679
Digital electronic instruments	624	Inspection and maintenance	682
Electronic instrument systems	625	Servicing the system	683
Warning lights and indicators	626	Fault diagnosis	686
Operation of warning lights and indicators	629	<i>Technical terms</i>	687
Checking instruments and indicators	630	<i>Review questions</i>	687
Checking electronic instruments	632		
<i>Technical terms</i>	632	<b>34 Seat belts and seating</b>	689
<i>Review questions</i>	632	Using seat belts	690
<b>31 Body-electrical components</b>	635	Inertia-reel seat belts	690
Windscreen wipers	636	Seat-belt lockers or grabbers	691
Wiper motors	637	Seat-belt rip-stitching	691
Wiper motor circuits	638	Pretensioned seat belts	692
Windscreen washers	640	Seat-belt load limiter	694
Windscreen wiper and washer controls	641	Seat-belt anchors	695
Rear-window defoggers	641	Checking seat belts	696
Horns	642	Child restraints	697
Central door-locking	643	Seating	697
Power windows	645	<i>Technical terms</i>	698
Electric mirrors	647	<i>Review questions</i>	698
Other electrical components	647		
<i>Technical terms</i>	648	<b>35 Supplemental restraint systems (SRS) and occupant safety</b>	699
<i>Review questions</i>	648	Air bags	700
		Deployment of a driver's air bag	700
<b>Part 6 - Safety, security and convenience</b>		Driver's air-bag system	701
		Driver's air-bag assembly	701
<b>32 Braking: ABS, traction control and vehicle stability</b>	651	Passenger's air bag	702
Antilock braking system (ABS)	652	Front air-bag system	704
ABS operation	653	Air-bag sensors	704
Main ABS components	656	Air-bag electrical circuit	706
Electronic brake-force distribution (EBD)	656	Side air bags	707
Hydraulic proportioning valves	658	Hybrid air bags	708
Traction control system (TCS)	659	Complete SRS	709
Traction control with vacuum components	661	Mechanically activated air bags	709
Electronic stability program (ESP)	663	Effects of deployed air bags	710
Service points	665	Air-bag service	711
<i>Technical terms</i>	666	Fault diagnosis	713
<i>Review questions</i>	666	Deploying air bags prior to disposal	713
		Air-bag do's and don'ts	714
<b>33 Air conditioning</b>	667	Occupant safety items	715
Heat	668	<i>Technical terms</i>	717
Principles of operation	668	<i>Review questions</i>	717

<b>36 Remote locking, immobilisers and security</b>	<b>719</b>	Arrangement of vacuum-type cruise control	740
Remote door-locking	720	Vacuum cruise control schematic	741
Basic remote locking system	720	Cruise control for diesel	743
Central door-locking system	721	Possible cruise control problems	744
Servicing keypads and keyheads	722	Trip computers	744
Vehicle immobilisers	723	Using a trip computer	744
An immobiliser system	725	Instrument panel displays	745
Immobiliser with transponder key	726	Other trip computer features	745
Features of immobiliser systems	727	Possible trip computer problems	747
Validation of a security code	728	<i>Technical terms</i>	747
Keypad operation and programming	729	<i>Review questions</i>	747
Fault diagnosis	730	<b>38 Audio systems</b>	<b>749</b>
Alarm systems	730	Radio reception	750
About electronic control modules	731	AM and FM signals	750
Steering locks	732	Conditions affecting radio reception	751
<i>Technical terms</i>	733	Noise suppression on the vehicle	752
<i>Review questions</i>	733	Audio controls	752
<b>37 Cruise controls and trip computers</b>	<b>735</b>	Audio security	753
Cruise control	736	Audio problems	754
Cruise control components	736	<i>Technical terms</i>	756
Cruise control switches	737	<i>Review questions</i>	756
Operating a cruise control	738	Glossary	757
Types of cruise control systems	739	Index	769